

October 2005

# Getting Started

All documentation is provided on the CD.

Also, go to the website <http://www.racing-instrumentation.com/progressive-controller/> and click through to "[downloads and technical docs](#)" for the most current documents.

1. Read "Typical Installation Configurations" to give you an idea how to configure your PROgressive Controller.
2. Read the "Do's and Don'ts".
3. Read "Installation Instructions" when ready to install.
4. Select the correct "Wiring Diagram" for your PROgressive Controller and follow the numbers.
5. Follow the "Software Instructions" for your PC.
6. Test the system before you race and have fun!

#### Disclaimer

Racing is a dangerous sport. If you engage in racing or any activity described in this document, you are acknowledging and assuming responsibility for all risks incurred. The progressive timer controller is not EPA certified and are not to be used on any emission controlled, street driven vehicle. The information herein is for reference only and is not an authoritative document. We are not liable for misuse, accidents, loss of property, personal injury or death.